



© Copyright 2011 Ecomaster Technology Corporation. All Rights Reserved.
The information contained in this manual is believed to be accurate and reliable.

Ecomaster Technology Corporation assumes no responsibility for any errors contained in this manual.

Ecomaster Technology Corporation reserves the right to make changes in the specifications and/or design of this product without prior notice.

The diagrams contained in this manual may also not fully represent the product that you are using and are there for illustration purposes only.

All mentioned company and product names are trademarks or registered trademarks of their respectable owners.

User's Manual

A. Package Content

- "LE2001" 2.5" HDD Enclosure
- USB 2.0 cable (Model:LE2001S)
- USB 3.0 cable (Model:LE2001U3)
- User's manual

B. Minimum System Requirements


1. Windows XP/Vista, and Windows 7
2. Mac OS 10.2, 10.3, and 10.4 or higher
*USB 3.0 was not available for Mac OS at the time this manual was written.
3. Computer with USB 3.0, 2.0 or 1.1 interface.

C. Installation


Please install your HDD as the following steps.

(Our products are suitable for SATA HDDs with 9.5 mm height only.)


1. Push the button on the bottom of case to release button cover, then slide out.




2. Take off bottom cover.




3. Install SATA HDD.




4. Slide HDD as below to make sure connection is completed.



5. Target the hook of the bottom cover to concave of the body.



6. Slide bottom to make sure connection is completed. It makes a "CLICK" sound.



If you can't install independently, please ask the local distributor for help.

D. Using your LE2001

Introduction

- If the HDD is for initiate use, please format it.
- try "Computer Management"—"Disk Management"—"Action"—"Rescan Disk" to find the device.

Caution

- Please don't put this external enclosure in a humid or high temperature environment.
- If the PC or this storage is damaged by fault operation of user, we would not take the responsibility of compensation or repair.

Unplug Procedure

- Unplug Procedure on a PC (Microsoft Windows) *
 1. Click on the taskbar icon for the external hardware
 2. Choose the external HDD and confirm to remove it
- Unplug Procedure on a Macintosh (Apple Mac OS) *
 1. Drag the external HDD icon into the trash bin, then you can remove it.

* For safe removal of your drive and assure no data is lost, always follow the unplug procedure. If not, errors message might show up.